

分體式、窗口分體式冷氣機安裝 Split-type & Window Split-type Air-conditioner Installation

<u>冷氣機類型 Types of Air-conditioner</u>	<u>基本安裝費用 Basic charge</u>
<ul style="list-style-type: none"> 一匹分體式或窗口分體式冷氣機 Split-type & window split-type air-conditioner standard installation for 1 HP 	\$1800
<ul style="list-style-type: none"> 一匹半分體式或窗口分體式冷氣機 Split-type & window split-type air-conditioner standard installation for 1.5 HP 	\$1900
<ul style="list-style-type: none"> 二匹分體式或窗口分體式冷氣機 Split-type & window split-type air-conditioner standard installation for 2 HP 	\$2000
<ul style="list-style-type: none"> 二匹半或以上分體式或窗口分體式冷氣機 Split-type & window split-type air-conditioner standard installation for 2.5 HP or above 	\$2200
<p>基本安裝包括: Standard installation includes:</p> <ul style="list-style-type: none"> 安裝白鋁架座台 Installation of a plain aluminum mounting rack 15 呎雪種喉,15 呎控制線, 15 呎去水喉 A 15ft surface refrigerant pipe, a 15ft control wire and a 15ft surface drain pipe 開玻璃窿一個 A glass opening 米色保溫膠 Beige pipe insulator (surface) 	

額外安裝項目收費表 (要求超過標準) :

Additional Installation Price List (For requirements exceed standard installation):

<u>項目 Item</u>		<u>收費 Charge</u>
<ul style="list-style-type: none"> ● 額外雪種喉連隔熱膠¹ Extra refrigerant pipe with insulation¹ <ul style="list-style-type: none"> ○ 7,000-14,000 BTU 每米 /meter \$125 ○ 14,001-18,500 BTU 每米 /meter \$135 ○ 18,501-28,000 BTU 每米 /meter \$150 		
<ul style="list-style-type: none"> ● 額外去水喉連隔熱膠² Additional drain pipe with insulation² 	每米 meter	\$45
<ul style="list-style-type: none"> ● 電源線或控制線獨立外加 PVC 喉保護 Separated PVC protection for power cord or control wire 	每米 meter	\$20
<ul style="list-style-type: none"> ● 鋁質掛牆散熱器承托架 Aluminum outdoor mounting rack <ul style="list-style-type: none"> ○ 如合適 · 四吋高以內坐地架 Floor stand mounting rack <4" high if applicable ○ 7,000-14,000 BTU 每個/each \$400 ○ 14,001-28000 BTU 每個/each \$450 		免費 FREE
<ul style="list-style-type: none"> ● 不鏽鋼掛牆散熱器承托架 Stainless steel outdoor mounting rack 	每個 each	\$600
<ul style="list-style-type: none"> ● 額外室內吊架/掛架 Extra indoor mounting rack 	每個 each	\$200
<ul style="list-style-type: none"> ● 雪種喉長超出廠商設定而添加 R410 雪種 Refilling extra refrigerant (R410) for pipe exceeding specification 	每部 set	\$200
<ul style="list-style-type: none"> ● 雪種喉長超出廠商設定而添加 R32 雪種 Refilling extra refrigerant (R32) for pipe exceeding specification 	每部 set	\$400
<ul style="list-style-type: none"> ● 窗口式分體坐窗台承托架 (不超越窗台面) Window split-type air-con setting rack for windowsill (not over windowsill surface) 	每個 each	\$200
<ul style="list-style-type: none"> ● 額外拉電線明線安裝 Extra surface wiring installation 	每米 meter	\$50

<u>項目 Item</u>		<u>收費 Charge</u>
<ul style="list-style-type: none"> 鑿牆窿 (只限非結構性磚牆) 小於 6 吋厚 Wall opening (non-structured brick wall only) <6" thick 	每個 each	\$200
<ul style="list-style-type: none"> 鑿牆窿 (只限非結構性磚牆) 6-10 吋厚 Wall opening (non-structured brick wall only) 6-10" thick 	每個 each	另行報價 Quote & Charge
<ul style="list-style-type: none"> 有燈開關制或插座安裝或改位 (每個計 · 包 3 米電線) Relocation or installation of switch with indicator light or socket (each includes a 3m wiring) 	每個 each	\$250
拆卸舊分體機及機架 (在安全情況下) : Uninstallation of existing split-type air-con and mounting rack (under safe circumstance):		
<u>項目 Item</u>		<u>收費 Charge</u>
<ul style="list-style-type: none"> 掛牆式分體機 Wall mount split-type air-con 		\$400
<ul style="list-style-type: none"> 窗口式分體機 Window split-type air-con 		\$300
<ul style="list-style-type: none"> 只拆室內機 Removing the indoor unit only 		\$150
<ul style="list-style-type: none"> 窗口冷氣機 Old window type air-con 		\$85
<ul style="list-style-type: none"> 拆窗出散熱器 Uninstalling and re-installing window for moving the outdoor unit 	每個 each	\$200
<ul style="list-style-type: none"> 鋸拆鋁窗框架或 T 骨出散熱器 Dismantling aluminum window frame for moving the outdoor unit 		\$200
<ul style="list-style-type: none"> 12mm 厚室外散熱器避震膠 12mm thick rubber shock absorber for outdoor unit 	每套 (4 件) each set (4 pcs)	\$160
<ul style="list-style-type: none"> 散熱器底加裝不鏽鋼水盤連 5 米去水喉 (選擇性安裝 · 冷 / 暖型分體機建議使用) Installation of a water tray with a 5m drain hose for outdoor unit (optional, recommended for cool & warm type SAC) 	每個 each	\$500
<ul style="list-style-type: none"> 室外機扯吊上高位安裝 (2 米以上) Hanging for over 2m to install the outdoor unit 	每個 each	\$300

法例訂明之安全要求 Safety measures in accordance with regulations:

項目 Item		收費 Charge
• 機尾掣 / 急停掣 Emergency switch	每個 each	\$200
• 防水刀掣 Waterproof isolator	每個 each	\$300
• 安全工作臺 / 棚架 Safety scaffolding		另行報價 Quote & Charge

離島·愉景灣及禁區內服務附加費 (東涌及珀麗免費)

 Additional service charge for outlying Island, Discovery Bay and forbidden zones.
 (Free for Tung Chung & Park Island)

• 首部 The 1 st unit		\$300
• 第二部起 From the 2 nd unit	每部 set	\$50

其他項目例如藏喉、新玻璃或額外工程保險等

Other items such as concealment of pipes, new glass, or extra installation insurance, etc.

 另行報價
Quote & Charge

備註 Remarks:

- (1) 分體式安放位置需由顧客確認及負責向大廈管業處取得許可，如安裝後顧客要求改位或重裝，需另報價收費。
Location of split-type air-conditioner is assigned by customer. Customer is responsible for applying permit from the building management party, if required. Any re-location or re-installation after installation shall be subjected to extra charge.
- (2) 電源需由顧客負責提供至機身電源線端的半米範圍。如需本公司安裝插座，價錢另議。
Customer should provide an electricity supply distant within 0.5m to the air-con connecting wire. Extra provision of this service is on quote and charge basis.
- (3) 標準安裝工程不包括代客申請任何認可牌照及登記註冊，如電錶、通風牌照等。
Standard installation does not include any application of license or registration such as electricity supply, ventilation, etc.
- (4) 安裝工程完成後，有關裝修粉飾之修補需由客戶自行處理。
After installation, customer is responsible for any follow-up decoration and finishing work.
- (5) 在安全情況下，安裝工程可能須配備棚架進行；8呎標準寬度棚架收費 \$3,500 起 (需視乎區域、環境有所調整)。
Under a safety circumstance, scaffolding may be used for installation. Basic charge for standard scaffolding in 8ft width is \$3,500 up (subject to district and service environment).

- (6) 標準安裝祇適用於住宅客戶。商舖、寫字樓、工廠等商用客戶，需先睇位報價。
Standard installation is only applicable to residential customers. Shops, offices, factories and commercial clients are subject to on-site inspection and quotation.
- (7) 保養及維修不包括搭棚及安全架，需由客戶負責提供。
Warranty and repair service do not include scaffolding or safety hanger, which shall be provided by customer if applicable.
- (8) 一年安裝工程保用包括冷氣機承托架、封窗玻璃膠及雪種喉接口雪種滲漏；惟不包括冷氣機因缺乏定期保養而引至排水設施淤塞，至於產品更換或清洗需額外收費。
1 year installation warranty covers only air-con supporting racks, silicone glass seal-up and leakage of refrigerant at pipe joints. Any air-con foul drain caused by absence of proper and regular routine maintenance is excluded from the warranty. Product replacement or cleansing are subject to extra charges.
- (9) 安裝於窗臺之分體機受位址所限並涉及玻璃拆封，客戶需承擔日後維修及保養之相關費用。
Split-type air-con which is installed at windowsill is restricted by spacing and involves glass re-fix. Customer is responsible for related repairing and maintenance charges afterwards.
- (10) 若因環境問題或其他因素重用現有雪種喉或排水管，客戶需承擔日後維修及保養之相關費用。
If existing refrigerant pipes or drain hoses are reused due to environmental or other factors, customer is responsible for related repairing and maintenance charges afterwards.
- (11) 額外 \$ 20,000,000.00 的第三者及公眾責任保險涵蓋安裝工程，超額要求需由客戶承擔（如大廈管業處要求）。
A public liability and third-party insurance of \$20,000,000.00 covers the installation. Any insurance of higher coverage shall be borne by the customer (such as upon building management party's requirement).
- (12) 如價格有任何修改，不作另行通知。未列出的收費項目將以現場報價為準。
Charges can be amended without prior notice. Non-listed items are subject to on-site quotation.

安裝小貼士 Installation Tips:

- 要注意家居面積大小、方向及樓層來決定冷氣機的匹數
Please take the size of the apartment, direction and floor into account for choosing the horsepower of the air-conditioner.

50 至 80 平方呎 50 to 80 sq. feet	$\frac{3}{4}$ 匹 $\frac{3}{4}$ HP
80 至 100 平方呎 80 to 100 sq. feet	1 匹 1 HP
100 至 140 平方呎 100 to 140 sq. feet	1.5 匹 1.5 HP
140 至 180 平方呎 140 to 180 sq. feet	2 匹 2 HP
180 至 250 平方呎 180 to 250 sq. feet	2.5 匹 2.5 HP
250 平方呎或以上 250 sq. feet or above	3 匹 3 HP

- 若冷氣機用於西斜房間，建議可加大半匹
It is recommended to increase the horsepower by 0.5 HP, if the air-conditioner is used in a room facing west.
- 若冷氣機用於天臺或頂樓正東方向，建議可加大半匹至一匹
It is recommended to increase the horsepower by 0.5 to 1 HP, if the air-conditioner is used on the rooftop or top floor facing east.
- 若用於客廳可加大半匹至一匹
It is recommended to increase the horsepower by 0.5 to 1 HP, if the air-conditioner is used in living room.

*以上資料只供參考，實際情況需按家居環境決定

*The above information is for reference only. The choice of horsepower depends on the actual circumstances of the apartment.